

Key Functions

* Network configuration via the L-Home APP, with support for setting RGB2W

16 Modes

Short press: switch
Long press: adjust current mode speed

Short press:
Turn RGB on/off
Long press:
Adjust the brightness value of RGB

Short Press:
All on/All off

16 Modes (Switch via the "⚙️")

1. 3 color jumping
2. 7 color jumping
3. White strobe
4. 7 color strobe
5. Red green gradient
6. Red blue gradient
7. Green blue gradient
8. Red yellow gradient
9. Blue purple gradient
10. Green yellow gradient
11. Blue cyan gradient
12. Red purple gradient
13. Blue white gradient
14. Yellow purple cyan gradient
15. 3 color gradient
16. Full color gradient



4 Zone Keys

Short press: Turn on, select/deselect the current zone
Long press: Turn off the current zone

Short press: Turn CW on/off

Long press: adjust the brightness value of CW

Touch Color Ring (RGB)

Touch Slider: CW

Four Scene Keys

Short press: Execute the scene
Long press: Save the current scene (This function needs to be enabled in the APP)


Wireless controlled lighting fixtures.



APP



WP05



Bluetooth Driver

Lamp